




Part numbers **in bold type** designate consumption parts.

Ref. No.	Part number	Qty	Description
1	8411 0307 48	1	Air motor LZB 33L A005 - 12 (see spare parts list No. 9836 1221)
2	6003 9372 10	1	Shaft (stainless steel)
3	6003 9298 10	1	Agitator for -GS2, (stainless steel, upwards flow)
3	6003 9298 00	1	Agitator for -G2, (upwards flow)
4	0111 1285 01	1	Pin (3,2 x 40 stainless steel)
5	6003 7827 00	1	Edge bracket, compl.
6	6803 6689 00	1	- Knob
7	0196 1319 00	2	Set screw (SK6SS 8 x 10)
8	9090 0508 00	1	Silencer (G1/4)
9	6003 9301 00	1	Needle valve
-	0663 6112 00	1	- O-ring (5.1 x 1.6)
-	0192 1168 00	1	- Set screw (T6SS 4 x 6)
10	6001 3762 00	1	- Nut (G1/4)

